



Model Maxi / KW901 Instruction Manual



TARE
FUNCTION



AUTO OFF



LIQUIDS



BATTERY
LEVEL

Visit www.frieling.com
for more information

Thank you for purchasing an ADE digital scale. Please read this instruction manual carefully before first use. Keep these instructions for future use.

Initial Setup and Battery Replacement

- This scale operates on one CR2032 battery (included).
- To install the included battery: pull the battery holder out of the bottom left side of the scale. Insert the battery according to polarity and re-insert the battery holder into the scale.



- Within 3 seconds of inserting the battery: you will hear a beep and the screen will display "hello".

Powering On/Off

- Hold the scale in the vertical position.
- Turn on the scale by pressing the black ON/OFF button on the top left of the scale. The scale will beep and the screen will display "hello".
- The scale will beep a second time and the display will show 0g or 0.0lb/oz. The scale is now ready for use.
- This scale is equipped with an auto-off feature to conserve battery power. The unit will turn off automatically after being idle for 1 minute.
- Turn the scale off manually by pressing the ON/OFF button.

Weight and Volume Measurement

- Press the black ON/OFF button while the screen shows "hello" to change the desired unit of measure (kg to lb/ lb to kg)

Instructions for Use

- While the scale is on and the screen displays 0.0 lb/kg: Unclip the strap on the bottom of the scale and re-attach around your luggage handle.
- Use the scale handle to lift your luggage off the ground.
- As soon as the weight is stable, a beep will sound and the weight will be display with the letter "H" (hold).
- You can now set your luggage back on the ground and comfortably read the weight.
- To weigh additional luggage: push the ON/OFF button. Once the scale beeps and the display shows 0.0 lb/ kg you are ready to weigh your next piece of luggage.

Tare Function

Hang the first item you would like to weigh on the scale. After the scale beeps and displays the weight with the letter "H", press the ON/OFF button while your luggage is still lifted off the ground to reset the scale to zero. One the display again reads zero you can place the items you would like to tare into the container. The scale will at this point weigh only the items in the container and not the container itself. This process can be repeated until the scale reaches its maximum capacity of 121 lbs/55 kg.

Error Messages

Lo = low battery indicator, replace with new battery (1 x CR2032).

Err = the scale is overloaded. Immediately remove weight from the scale to prevent damage.

Specifications

Scale Capacity: 121 lbs, 55 kg

Display Size: 1 1/2" x 3/4"

Battery: 1 x CR2032 (included)

Statutory instructions on battery disposal

Batteries must not dispose as of household waste. The law requires that you, as consumer, return the waste batteries either to public collection points in your town or village or to any outlet selling batteries of the same kind.



Batteries are marked as follows:

Li = Battery contains Lithium

Al = Battery contains Alkali

Mn = Battery contains Manganese

CR (Li); A (Al, Mn); AA (Al, Mn); AAA (Al, Mn)

Disposal of old electrical and electronic equipment



This symbol on the product or on its packaging indicates that this product shall not be treating as household waste. Instead, it shall be handed over to the applicable collection point for recycling of electrical and electronic equipment. For more detailed information's about recycling please contact your local city office, your household waste disposal service or the shop where you purchased the product.

Warranty

ADE warrants for a period of 3 years from the date of purchase that it will remedy any defects due to faulty material or workmanship free of charge by repair or replacement.

If you believe you have a warranty claim, please call FRIELING USA, INC. at 800.827.2582 (or 704.329.5100) between 9:00 a.m. and 4 p.m. Mo - Fri EST before returning the scale.



CE Declaration of Conformity

**This device features radio interference suppression
in compliance with valid EC Regulation 2004/108**

Note: The displayed value may be adversely affected under extreme electromagnetic influences, e.g. when using a radio unit in the immediate vicinity of the device. Once the interference has been rectified, the product can once again be used for its intended purpose. The device may have to be switched-on again.

✂-----

Warranty card - 3 years warranty for the Digital Kitchen Scale

• Sender

• Reason for complaint

• Date of purchase _____

Please return this warranty card together with the receipt to:

Frieling USA, Inc.
1920 Center Park Drive
Charlotte, NC 28217

Instruction Manual: KW901