



MARIENBAD

(DISCONTINUED AFTER 03/2021)

ITEM DESCRIPTION	PU ¹	Item-No ²
 Coffee pot 1 0,35 ltr. / 11.7 oz.	2	001.539906
 Tea pot 1 0,35 ltr. / 11.7 oz.	2	001.540481
 Sugar bowl 2 0,23 ltr. / 7.7 oz.	1	001.540795
 Sugar dish 9 cm / 3.5 inch	12	001.540650
 Creamer 1 0,16 ltr. / 5.3 oz.	1	001.541154
 Coffee cup 1 0,18 ltr. / 6.0 oz.	6	001.541945
 Saucer 1 15 cm / 6.0 inch	6	001.541802
 Chocolate cup 0,23 ltr. / 7.3 oz.	6	001.543407
 Saucer 1 15 cm / 6.0 inch	6	001.541802
 Mocha cup 0,09 ltr. / 3.0 oz.	12	001.541679
 Saucer 12 cm / 4.8 inch	12	001.541584
 Milkcoffee cup 0,25 ltr. / 8.3 oz.	6	001.542497
 Saucer 1 15 cm / 6.0 inch	6	001.541802
 Set salt and pepper	1	001.539326
 Mug with handle 0,30 ltr. / 10.0 oz.	6	001.543168

¹ PU = Packing Unit

² Item-No. refers to undecorated articles

ITEM DESCRIPTION	PU ¹	Item-No ²
 Plate flat with rim 30 cm / 12.0 inch	6	001.537146
 Plate flat with rim 27 cm / 10.6 inch	6	001.537002
 Plate flat with rim 25 cm / 9.9 inch	6	001.536858
 Plate flat with rim 21 cm / 8.2 inch	6	001.536714
 Plate flat with rim 19 cm / 7.5 inch	6	001.536570
 Plate flat with rim 17 cm / 6.8 inch	6	001.536426
 Plate flat with rim 15 cm / 6.0 inch	6	001.536282
 Plate deep with rim 23 cm / 9.0 inch	6	001.537289
 Plate deep with rim 19 cm / 7.5 inch	6	001.538465
 Soup cup 0,30 ltr. / 10.0 oz.	6	001.537624
 Saucer 1 15 cm / 5.9 inch	6	001.541802
 Gravy boat 0,50 ltr. / 16.7 oz.	2	001.538656
 Gravy boat 0,15 ltr. / 5.0 oz.	4	001.538824
 Butter pad 0,04 ltr. / 1.3 oz.	2	001.538751
 Bowl round 13 cm / 5.1 inch	6	001.537721
 Bowl round 15 cm / 6.0 inch	4	001.537841
 Bowl round 18 cm / 7.1 inch	2	001.537962
 Bowl round 20 cm / 7.7 inch	2	001.538106
 Bowl round 23 cm / 9.0 inch	2	001.538249
 Bowl round 25 cm / 9.9 inch	2	001.538368
 Oval platter 28 cm / 10.6 x 7.1 inch	2	001.539378
 Oval platter 31 cm / 12.0 x 8.1 inch	2	001.539522
 Oval platter 35 cm / 13.6 x 9.3 inch	2	001.539665
 Oval platter 38 cm / 14.6 x 9.9 inch	2	001.539785
 Oval platter 24 cm / 9.3 x 5.0 inch	2	001.539042

