



COUP FINE DINING

COUNTRY LIFE

ITEM DESCRIPTION	PU ¹	Item-No
 Showplate flat M5380 33 cm / 13.1 inch	4	001.731546 ² 001.731560 ³
 Plate flat coup M5380 30 cm / 12.0 inch	6	001.731540 ² 001.731554 ³
 Plate flat coup M5380 28 cm / 11.1 inch	6	001.731539 ² 001.731553 ³
 Plate flat coup M5380 26 cm / 10.3 inch	6	001.731538 ² 001.731552 ³
 Plate flat coup M5380 21,5 cm / 8.5 inch	6	001.731537 ² 001.731551 ³
 Plate flat coup M5380 16,5 cm / 6.5 inch	6	001.731536 ² 001.731550 ³
 Bowl coup M5381 28 cm / 11.0 inch	4	001.731545 ² 001.731559 ³
 Bowl coup M5381 26 cm / 10.3 inch	6	001.731544 ² 001.731558 ³
 Bowl coup M5381 23 cm / 9.2 inch	6	001.731543 ² 001.731557 ³
 Bowl coup M5381 20 cm / 7.9 inch	6	001.731542 ² 001.731556 ³
 Bowl coup M5381 14,5 cm / 5.7 inch	6	001.731541 ² 001.731555 ³
 Platter coup M5379 33 x 18 cm / 13.0 x 7.0 inch	2	001.733793 ² 001.733795 ³
 Platter coup M5379 40 x 25,5 cm / 15.9 x 10.2 inch	2	001.731547 ² 001.731561 ³
 Platter coup M5379 43 x 19 cm / 17.1 x 7.5 inch	2	001.731548 ² 001.731562 ³
 Platter coup M5379 35 x 11 cm / 13.9 x 4.5 inch	2	001.733792 ² 001.733794 ³
 Platter coup M5379 44 x 14 cm / 17.4 x 5.6 inch	2	001.731549 ² 001.731563 ³
 Setplatter 44 cm / 17.5 x 5.6 inch	2	001.732812 ² 001.732815 ³
 Bowl high 0,18 ltr. / 6.3 oz.	6	001.732811 ² 001.732814 ³
 Bowl low 0,21 ltr. / 6.7 oz.	6	001.732810 ² 001.732813 ³

¹ PU = Packing Unit

ITEM DESCRIPTION	PU ¹	Item-No
 Coffee pot 1 0,36 ltr. / 12.0 oz.	2	001.731968 ² 001.731991 ³
 Sugar bowl 2 0,23 ltr. / 7.7 oz.	1	001.731969 ² 001.731992 ³
 Creamer 2 0,23 ltr. / 7.7 oz.	1	001.731970 ² 001.731993 ³
 Mocha cup 1132 0,09 ltr. / 3.0 oz.	6	001.731972 ² 001.731995 ³
 Saucer 1132 12 cm / 4.7 inch	6	001.731971 ² 001.731994 ³
 Cup 1163 0,18 ltr. / 6.0 oz.	6	001.731977 ² 001.732001 ³
 Saucer 1163 14,7 cm / 5.8 inch	6	001.731976 ² 001.731999 ³
 Cappuccino cup 1131 0,22 ltr. / 7.3 oz.	6	001.731975 ² 001.731998 ³
 Saucer 1131 14,7 cm / 5.8 inch	6	001.731974 ² 001.731997 ³
 Cup 1164 0,37 ltr. / 12.3 oz.	6	001.731979 ² 001.732003 ³
 Saucer 1164 16 cm / 6.3 inch	6	001.731978 ² 001.732002 ³
 Cup without handle 5041 0,50 ltr. / 16.7 oz.	6	001.731973 ² 001.731996 ³
 Mug with handle non stackable 5005 0,25 ltr. / 8.3 oz.	6	001.731989 ² 001.732004 ³
 Mug with handle non stackable 5025 0,40 ltr. / 13.3 oz.	6	001.731990 ² 001.732005 ³

[2] »Champagne« 57010

[3] »Petrol« 57011





COUP FINE DINING COUNTRY LIFE

ITEM DESCRIPTION	PU ¹	Item-No
 Showplate flat M5380 33 cm / 13.1 inch	4	001.731574 ⁴ 001.731588 ⁵
 Plate flat coup M5380 30 cm / 12.0 inch	6	001.731568 ⁴ 001.731582 ⁵
 Plate flat coup M5380 28 cm / 11.1 inch	6	001.731567 ⁴ 001.731581 ⁵
 Plate flat coup M5380 26 cm / 10.3 inch	6	001.731566 ⁴ 001.731580 ⁵
 Plate flat coup M5380 21,5 cm / 8.5 inch	6	001.731565 ⁴ 001.731579 ⁵
 Plate flat coup M5380 16,5 cm / 6.5 inch	6	001.731564 ⁴ 001.731578 ⁵
 Bowl coup M5381 28 cm / 11.0 inch	4	001.731573 ⁴ 001.731587 ⁵
 Bowl coup M5381 26 cm / 10.3 inch	6	001.731572 ⁴ 001.731586 ⁵
 Bowl coup M5381 23 cm / 9.2 inch	6	001.731571 ⁴ 001.731585 ⁵
 Bowl coup M5381 20 cm / 7.9 inch	6	001.731570 ⁴ 001.731584 ⁵
 Bowl coup M5381 14,5 cm / 5.7 inch	6	001.731569 ⁴ 001.731583 ⁵
 Platter coup M5379 33 x 18 cm / 13.0 x 7.0 inch	2	001.733797 ⁴ 001.733799 ⁵
 Platter coup M5379 40 x 25,5 cm / 15.9 x 10.2 inch	2	001.731575 ⁴ 001.731589 ⁵
 Platter coup M5379 43 x 19 cm / 17.1 x 7.5 inch	2	001.731576 ⁴ 001.731590 ⁵
Platter coup M5379 35 x 11 cm / 13.9 x 4.5 inch	2	001.733796 ⁴ 001.733798 ⁵
Platter coup M5379 44 x 14 cm / 17.4 x 5.6 inch	2	001.731577 ⁴ 001.731591 ⁵
Setplatter 44 cm / 17.5 x 5.6 inch	2	001.732818 ⁴ 001.732821 ⁵
Bowl high 0,18 ltr. / 6.3 oz.	6	001.732817 ⁴ 001.732820 ⁵
Bowl low 0,21 ltr. / 6.7 oz.	6	001.732816 ⁴ 001.732819 ⁵

¹ PU = Packing Unit

ITEM DESCRIPTION	PU ¹	Item-No
 Coffee pot 1 0,36 ltr. / 12.0 oz.	2	001.732006 ⁴ 001.732020 ⁵
 Sugar bowl 2 0,23 ltr. / 7.7 oz.	1	001.732007 ⁴ 001.732021 ⁵
 Creamer 2 0,23 ltr. / 7.7 oz.	1	001.732008 ⁴ 001.732022 ⁵
 Mocha cup 1132 0,09 ltr. / 3.0 oz.	6	001.732010 ⁴ 001.732024 ⁵
 Saucer 1132 12 cm / 4.7 inch	6	001.732009 ⁴ 001.732023 ⁵
 Cup 1163 0,18 ltr. / 6.0 oz.	6	001.732015 ⁴ 001.732029 ⁵
 Saucer 1163 14,7 cm / 5.8 inch	6	001.732014 ⁴ 001.732028 ⁵
 Cappuccino cup 1131 0,22 ltr. / 7.3 oz.	6	001.732013 ⁴ 001.732027 ⁵
 Saucer 1131 14,7 cm / 5.8 inch	6	001.732012 ⁴ 001.732026 ⁵
 Cup 1164 0,37 ltr. / 12.3 oz.	6	001.732017 ⁴ 001.732031 ⁵
 Saucer 1164 16 cm / 6.3 inch	6	001.732016 ⁴ 001.732030 ⁵
 Cup without handle 5041 0,50 ltr. / 16.7 oz.	6	001.732011 ⁴ 001.732025 ⁵
 Mug with handle non stackable 5005 0,25 ltr. / 8.3 oz.	6	001.732018 ⁴ 001.732032 ⁵
 Mug with handle non stackable 5025 0,40 ltr. / 13.3 oz.	6	001.732019 ⁴ 001.732033 ⁵

[4] »Oliv« 57012

[5] »Terracotta« 57013

