




SAVOY

ITEM DESCRIPTION	PU ¹	Item-No ²
 Coffee pot 1 0,30 ltr. / 10.0 oz.	2	001.505082
 Tea pot 1 0,40 ltr. / 13.3 oz.	2	001.505355
 Tea pot 2 0,75 ltr. / 25.0 oz.	2	001.505628
 Warming plate small	1	001.509840
 Sugar bowl 2 0,25 ltr. / 8.3 oz.	1	001.506564
 Sugar dish 8 cm / 3.2 inch	12	001.506447
 Creamer 00 0,03 ltr. / 1.0 oz.	12	001.506837
 Creamer 1 0,15 ltr. / 5.0 oz.	1	001.506954
 Creamer 2 0,25 ltr. / 8.3 oz.	1	001.507071
 Coffee cup 1 0,18 ltr. / 6.0 oz.	6	001.508787
 Saucer 1 16,4 cm / 6.5 inch	6	001.508631
 Mocha cup 0,09 ltr. / 3.0 oz.	12	001.508514
 Saucer 14,5 cm / 5.7 inch	12	001.508358
 Breakfast cup 0,36 ltr. / 12.0 oz.	6	001.509606
 Saucer 1 16,4 cm / 6.5 inch	6	001.508631
 Milkcoffee cup 0,22 ltr. / 7.3 oz.	6	001.509333
 Saucer 1 16,4 cm / 6.5 inch	6	001.508631
 Coffee cup non stackable 0,18 ltr. / 6.0 oz.	6	001.507968
 Saucer 1 16,4 cm / 6.5 inch	6	001.508631
 Mocha cup non stackable 0,09 ltr. / 3.0 oz.	12	001.508241
 Saucer 14,5 cm / 5.7 inch	12	001.508358
Chocolate cup non stackable 0,22 ltr. / 7.7 oz.	6	001.507422
Saucer 1 16,4 cm / 6.5 inch	6	001.508631
Milkcoffee cup non stackable 0,37 ltr. / 12.3 oz.	6	001.507695
Saucer 1 16,4 cm / 6.5 inch	6	001.508631
Mug with handle 0,25 ltr. / 8.3 oz.	6	001.509723
Egg cup with rest	6	001.502742
Set salt and pepper	1	001.503600
Vase	2	001.509879
Candleholder	2	001.510230
Ash tray	4	001.510113
Party-spoon	6	001.510347
Bowl sloping 8,5 cm / 3.4 inch	6	001.498374
Bowl sloping 11 cm / 4.4 inch	6	001.498881
Bowl square 9 cm / 3.5 x 3.5 inch	6	001.498491
Bowl square 11 cm / 4.8 x 4.8 inch	6	001.498764

¹ PU = Packing Unit

² Item-No. refers to undecorated articles

ITEM DESCRIPTION	PU ¹	Item-No ²
 Plate flat with rim 34 cm / 13.4 inch	2	001.501143
 Plate flat with rim 33 cm / 13.0 inch	6	001.497321
 Plate flat with rim 30 cm / 12.0 inch	6	001.497165
 Plate flat with rim 28 cm / 11.3 inch	6	001.497009
 Plate flat with rim 26 cm / 10.4 inch	6	001.496853
 Plate flat with rim 23 cm / 9.3 inch	6	001.496697
 Plate flat with rim 21 cm / 8.5 inch	6	001.496541
 Plate flat with rim 18 cm / 6.8 inch	6	001.496385
 Plate flat with rim 16 cm / 6.5 inch	6	001.496307
 Gourmetplate round 30 cm / 12.0 inch	2	001.500363
 Gourmetplate round 27 cm / 10.6 inch	2	001.500519
 Gourmetplate round 21 cm / 8.5 inch	6	001.501065
 Gourmetplate round 18 cm / 7.3 inch	6	001.500987
 Gourmetplate round 16 cm / 6.5 inch	6	001.500675
 Gourmetplate round 12 cm / 4.8 inch	6	001.500831
 Plate deep with rim 23 cm / 9.2 inch	6	001.497477
 Salad plate deep 19 cm / 7.6 inch	6	001.500168
 Soup cup 0,27 ltr. / 9.0 oz.	6	001.497789
 Saucer 1 16,4 cm / 6.5 inch	6	001.508631
 Eventbowl 5253 18 cm / 7.0 x 4.8 inch	4	001.697323
 Tureen 2,90 ltr. / 96.7 oz.	1	001.501260
Gravy boat 0,35 ltr. / 11.7 oz.	2	001.501767
Gravy boat 0,15 ltr. / 5.0 oz.	4	001.502625
Butter pad 0,04 ltr. / 1.3 oz.	2	001.502508
Bowl round 12 cm / 4.7 inch	6	001.497906
Bowl round 14 cm / 5.5 inch	4	001.498062
Bowl round 17 cm / 6.6 inch	2	001.498218
Bowl round 20 cm / 7.8 inch	2	001.498608
Bowl round 22 cm / 8.5 inch	2	001.498998
Bowl round 24 cm / 9.3 inch	2	001.499154
Bowl round 13 cm / 5.2 inch	4	001.499934
Bowl round 15 cm / 6.0 inch	4	001.500051
Oval platter 28 cm / 11.0 x 7.6 inch	2	001.504458
Oval platter 32 cm / 12.8 x 8.7 inch	2	001.504614
Oval platter 36 cm / 14.6 x 10.0 inch	2	001.504770
Plate rectangular 36 x 14 cm / 14.2 x 5.5 inch	2	001.504146
Plate rectangular 30 x 14 cm / 11.8 x 5.5 inch	2	001.503990
Plate rectangular 23 x 14 cm / 9.1 x 5.5 inch	2	001.503834
Plate rectangular 16 x 12 cm / 6.3 x 4.7 inch	2	001.503678
Duo plate 26 cm / 10.6 x 6.0 inch	2	001.504926
Bowl square 14 cm / 5.7 x 5.7 inch	6	001.499310
Bowl square 17,5 cm / 7.0 x 7.0 inch	2	001.499466
Bowl square 22 cm / 8.7 x 8.7 inch	2	001.499622

